



KING OF TYRES

TRACTOR RADIAL TYRES

Descrizione
COP. 280/85R24 TL (11.2) 115A8/112B LR861 LEAO
COP. 320/85R24 TL (12.4) 122A8/119B LR861 LEAO
COP. 340/85R24 TL (13.6) 125A8/122B LR861 LEAO
COP. 360/70R24 TL 122A8/119B LR700 LEAO
COP. 380/70R24 TL (14.9) 125A8/125B LR700 LEAO
COP. 380/85R24 TL (14.9) 131A8/128B LR861 LEAO
COP. 420/70R24 TL (16.9) 130A8/127B LR700 LEAO
COP. 440/65R24 TL 131A8/128D LR650 LEAO
COP. 480/65R24 TL (18.4) 136A8/133D LR650 LEAO
COP. 480/70R24 TL (18.4) 138A8/135B LR700 LEAO
COP. 540/65R24 TL 143A8/140D LR650 LEAO

Descrizione
COP. 320/85R28 TL (12.4) 124A8/121B LR861 LEAO
COP. 340/85R28 TL (13.6) 127A8/124B LR861 LEAO
COP. 380/85R28 TL (14.9) 133A8/130B LR861 LEAO
COP. 420/70R28 TL (16.9) 139A8/136B LR700 LEAO
COP. 440/65R28 TL 134A8/131D LR650 LEAO
COP. 480/65R28 TL (18.4) 139A8/136D LR650 LEAO
COP. 480/70R28 TL (18.4) 140A8/137B LR700 LEAO
COP. 540/65R28 TL 145A8/142D LR650 LEAO
COP. 600/65R28 TL 150A8/147D LR650 LEAO

Descrizione
COP. 380/85R30 TL (14.9) 135A8/132B LR861 LEAO
COP. 420/85R30 TL (16.9) 140A8/137B LR861 LEAO
COP. 460/85R30 TL (18.4) 145A8/142B LR861 LEAO
COP. 540/65R30 TL 153A8/150D LR650 LEAO
COP. 420/85R34 TL (16.9) 142A8/139B LR861 LEAO
COP. 460/85R34 TL (18.4) 147A8/144B LR861 LEAO
COP. 480/70R34 TL (18.4) 143A8/143B LR700 LEAO
COP. 540/65R34 TL 148A8/145D LR650 LEAO

Descrizione
COP. 420/85R38 TL (16.9) 144A8/141B LR861 LEAO
COP. 460/85R38 TL (18.4) 149A8/146B LR861 LEAO
COP. 480/70R38 TL (18.4) 145A8/142B LR700 LEAO
COP. 520/70R38 TL (20.8) 150A8/150B LR700 LEAO
COP. 520/85R38 TL (20.8) 155A8/152B LR861 LEAO
COP. 580/70R38 TL 155A8/155B LR700 LEAO
COP. 600/65R38 TL 156A8/153D LR650 LEAO
COP. 650/65R38 TL 160A8/157D LR650 LEAO